


Parts List

No.	Part #	Description	L-6-C	L-8-C	L-8-LC	L-12-C	L-16-C	L-6-P	L-8-SP	L-8-P	L-12-P	L-12-SC	L-12-SP
1	108045-01	Spring Anchor Bar	2	2				2	2				
1	108499-01	Spring Anchor Bar			2	2	2			2	2	2	2
2	108044-01	Back Plate	1	1	2	2	2	1	1	2	2	2	2
3	108042-91	Frame	1	1				1	1				
3	108498-91	Frame			1	1	1			1	1	1	1
4	L-1259	Base Angle	2	2				2	2				
4	L-1275-L	Base Angle	1			1	1			1	1	1	1
4	L-1275-R	Base Angle	1			1	1			1	1	1	1
5	114372-01	Discharge Manifold Bracket										2	2
5	114369-01	Discharge Manifold Bracket	1			2		1			2		
5	L-1320-1	Discharge Manifold Bracket		1			2		1				
5	113430-01	Discharge Manifold Bracket			2					2			
6	L-1254-A	Intake Manifold	1										
6	L-1267	Intake Manifold			1								
6	L-1273-A	Intake Manifold					1						
6	L-1313-A	Intake Manifold				1							
6	L-1315-A	Intake Manifold		1									
6	113434-01	Intake Manifold									1		
6	113428-01	Intake Manifold								1			
6	113573-01	Intake Manifold							1				
6	113600-01	Intake Manifold						1					
6	114171-01	Intake Manifold											1
6	111045	Intake Manifold										1	
7	114368-01	Hose Coupling	6		8	12		6		8	12		
7	114370-01	Hose Couplings		8			16		8			12	12
8	L-1253	Drive Shaft	1	1				1	1				
8	L-1321	Drive Shaft	1			1	1			1	1	1	1
9A	90554	5/16-18 NC x 1-3/4 Sq HD MB	4	4	4	2	2	4	4	4	2	2	4
9B	90578	5/16-18 NC x 1 Carriage Bolt	2	2	4	4	4	2	2	4	4	4	4
10	90620	1/4 x 20 x 1 Plated						4	4	4	4		4
11	90651	3/8 x 16 x 1 Plated	6	6	6	6	6	6	6	6	6	6	6
12	92015	1/4-20 Hex Nut						4	4	4	4		4
13	92023	5/16-18 Wing Nut	6	4	8	8	8	6	4	8	8	8	8
14	92024	3/8-16 Hex Nut	10	10	10	10	10	10	10	10	10	10	10
15	93005	1/4 Lock Washer						4	4	4	4		4
16	93010	5/16 Flat Washer	6	6	8	8	8	6	6	8	8	8	8

Parts List

No.	Part #	Description	L-6-C	L-8-C	L-8-LC	L-12-C	L-16-C	L-6-P	L-8-SP	L-8-P	L-12-P	L-12-SC	L-12-SP
17	90653	3/8-16 x 1-1/4 Plated	4	4	4	4	4	4	4	4	4	4	4
18	93011	3/8 Flat Washer	8	8	8	8	8	8	8	8	8	8	8
19	93024	3/8 Lock Washer	4	4	4	4	4	4	4	4	4	4	4
20	90555	5/16-18 x 2 SQ HD				2	2				2	2	
21	87250	5/16" Hose		8			16		8			12	12
21	87249	1/2" Hose	6		8	12		6		8	12		
22	A-3656-A	Nylon Bushing Mainshaft	2	2	2	2	2	2	2	2	2	2	2
23	95528	Hose Clamp		16			32		16			24	24
23	S-5752	Hose Clamp	12		16	24		12		16	24		
24	A-3557	#4 x 3/16 Drive Screw	2	2	2	2	2	2	2	2	2	2	2
25	L-4627	1/32" Shim	2	2	4	4	4	2	2	4	4	4	4
26	L-4628	3/64" Shim	2	2	4	4	4	2	2	4	4	4	4
27	108096-01	Roller		3				3					
27	108097-01	Roller	3				3						
27	108507-01	Roller			3	3				3	3		
27	114172-01	Roller					3				3		3
28	L-1257	1/2" Cap	3		4	4		3		4	4		
28	L-1257-A	5/16" Cap		3			6		3			6	
29	113431-01	Manifold Cap						1	1	1	1		1
30	L-1266	Manifold Plug 1-1/4"			2	2	2			2		2	
30	L-1264	Manifold Plug 1"	2	2				2	2				
31	L-1261	Back Spring	4	4	8	4	4	4	4	8	4	4	4
31	L-4458	Back Spring		4			4				4	4	4
32	L-1463	Roller Arm Assembly	2	2	2	2	2	2	2	2	2	2	2
33	L-1440	Back Up Roller Assembly			1	1				1	1		1
33	L-4450	Back Up Roller Assembly										1	
34	H-12	Collar Set			2	2	2			2	2	2	2
35	L-4457	Bolt Spacer				2	2				2	2	2
36	L-4452	Hose Adaptor						6		8	12		
36	113571-01	Hose Coupling		8									12
37	113425-01	Lower Right Clamp						1	1	1	1		1
38	113426-01	Lower Left Clamp						1	1	1	1		1
39	113427-01	Manifold Clamp						2	2	2	2		2
40	113432-01	90˚ Elbow						1	1	1	1		1
41	L-1452	Roller Bushing (Nylon)	6	6	6	6	6	6	6	6	6	6	6

Designs and specifications change from time to time, CDS-John Blue reserves the right to alter or upgrade equipment as necessary. Always make sure you have the most current parts list before ordering replacement parts.